



INSTRUCTIONS on how to install your SHACKLE LOCK

- 1. Boil a jug
- Insert your black and white pieces for your 'shackle lock' into a cup of hot water
- 3. Leave these in the water for approx. 1 minute
- 4. Take a teaspoon and take the 'black' part of the lock and lay on a flat service
- 5. Take the chain link and push down over the lock this should sit into the chain link. Make sure you have the 'hole' of the black part at the TOP
- Next using a teaspoon, take the 'white' piece of the lock and using something like the back of a spoon, push the white part into the black hole of the lock
- 7. Your shackle lock is ready to use!

Hint:

Try not to let your shackle lock pieces cool down too much before you insert them into the chain link as they will harden as they cool. This makes it a bit harder to insert

Please note: when using hot water, please take care not to spill this onto your skin

The best way to retrieve the piece from the cup of hot water – is to use a spoon

